


OGS1822 Grass Shear + Shrubber XXX

5133002830 - OGS1822 - 4000462044





4000462044



Position	Quantity	Description	Part number	EAN
1009	1	BLADE	5131009078	4058546044954
1011	8	SCREW	5131000000	
1013	1	SWITCH	5131016262	4058546103675
1015	1	CONTACT PLATE	5131000000	
1016	1	SPRING	5131016193	4058546103507
1017	1	PUSH-BUTTON	5131039518	4058546043766
1019	1	SPRING	5131000000	
1020	1	TRIGGER	5131039519	4058546043773
1024	1	GEAR	5131039520	4058546043780
1025	1	MOTOR	5131006711	4058546044923
1029	1	MOTOR SUPPORT	5131008434	4058546092719
1033	1	GEAR	5131009074	4058546044916
1034	1	GEAR	5131009073	4058546093785
1037	1	KNOB	5131008432	4058546044909
1045	1	SLIDE	5131039521	4058546043797
1046	1	SPRING	5131034745	4058546143381
1048	1	SWITCH	5131039522	4058546043803
1049	1	ELECTRONIC	5131039523	4058546043810
1012	1	RAC308 SHRUBBER BLADE OGS1820 EMEA	5132002457	4892210813541
1043	1	RAC314 12cm Grass Shear XXX	5132003309	4960673138270