


# R18CSP-0 Circ Saw 18V XXX

5133002628 - R18CSP-0 - 4000444845





4000444845



<b>Position</b>	<b>Quantity</b>	<b>Description</b>	<b>Part number</b>	<b>EAN</b>
1007	1	BUTTON	5131038721	4058546018740
1008	1	DUST GUARD	5131038722	4058546018757
1019	1	SWITCH	5131038723	4058546018764
1020	1	SPRING	5131017871	4058546019983
1025	1	DC-MOTOR	5131038724	4058546018771
1026	1	GEAR BOX	5131038725	4058546018788
1030	1	EDGE GUIDE	5131001023	4058546338626
1031	1	CLAMPING FLANGE	5131030407	4058546124625
1032	1	FLANGE	5131001795	4058546083298
1033	1	SCREW	5131030406	4058546124618