

SK: NÁVOD NA POUŽITIE

ZAPNUTIE – Prepnite prepínač (spodná strana sviečky) do polohy ON.

VYPNUTIE – Prepnite prepínač (spodná strana sviečky) do polohy OFF.

Batérie: Otvorte kryt na batérie na spodnej strane LED sviečky. Vložte batérie. Dodržiavajte správnu polaritu. Ak batérie dlhší čas nepoužívate vytiahnite ich. Vytečené alebo poškodené batérie môžu spôsobiť popáleniny kyselinou pri kontakte s pokožkou, pri manipulácii s nimi používajte vhodné ochranné rukavice. Nenechávajte v dosahu detí, nedemontujte, neskratujte ani nevhádzajte do ohňa. Nikdy nenabíjajte nenabíjateľné batérie. Existuje riziko výbuchu!

Udržujte LED sviečku neumiestňujte do blízkosti zdrojov tepla a nepoužívajte ju vo vlhkom prostredí.



Výrobok nevyhadzujte do bežného domového odpadu, separujte oddelene lebo môže obsahovať súčasti nebezpečné pre životné prostredie alebo zdravie ľudí. Za účelom správnej likvidácie výrobku ho odovzdajte na mieste predaja, kde bude prijatý zdarma alebo u predajcu, ktorý predáva identický výrobok vzhľadom na jeho ráz a funkciu. Výrobok môžete odovzdať aj miestnej organizácii zaoberajúcej sa likvidáciou elektroodpadu. Týmto chránite životné prostredie, zdravie ostatných aj svoje. Prípadne otázky Vám zodpovie Váš predajca alebo miestna organizácia zaoberajúca sa likvidáciou elektroodpadu.

8091289 Model 2400408

Farba LED žltá

Počet LED 1

Stupeň ochrany Interiér IP20

Menovité napätie 3V

Menovitý príkon 0,12 W

Funkcie plápolanie plameňa

Napájanie 1 x CR2032 batéria (súčasťou balenia)

EN: INSTRUCTION MANUAL

ON - Press this button to turn on candle light.

OFF - Press this button to turn off candle light.

Batteries: Open the battery cover on the bottom of the LED candle. Insert the batteries. Observe the correct polarity. If batteries not use for a long time, pull them out. Leaking or damaged batteries can cause burns if exposed to the skin, use suitable protective gloves when handling them. Keep out of reach of children, do not disassemble, shorten or throw into the fire. Never charge non-rechargeable batteries. There is a risk of an explosion!

Keep your LED candle away from heat and condensation.



Waste equipment must not be collected separately or disposed of with household waste because it may contain components hazardous to the environment or health. Use or waste equipment may be dropped of free or charge at the point of sale, or at any distributor which sales equipment of identical nature and function. Dispose of product at a facility specializing in the collection of electric waste. By doing so, you will protect the environment as well as the health of others and yourself. If you have any questions, contact the local waste management organization. We shall undertake the tasks pertinent to the manufacturer as prescribed in the relevant regulations and shall bear any associated costs arising.

8091289 Model 2400408

LED color yellow

Number of LEDs 1

Degree of protection Interior IP20

Rated voltage 3V

Rated power input 0,12 W

Functions flaming flame

Power supply 1 x CR2032 battery (include)