


# R18CS7-0 BL Circular Saw XXX

5133002890 - R18CS7-0 BL - 4000462221





4000462221



Position	Quantity	Description	Part number	EAN
1001	3	SCREW	5131041198	4058546064624
1002	7	SCREW	5131026648	4058546056896
1003	1	SPRING	5131000000	
1004	1	BUTTON	5131041199	4058546064631
1005	1	SCREW	5131041200	4058546064648
1006	1	SWITCH	5131041201	4058546064655
1007	4	SCREW	5131041202	4058546064662
1008	1	HOUSING	5131041203	4058546064679
1009	1	WRENCH	5131041204	4058546064686
1010	1	STOPPER	5131019717	4058546108663
1011	8	SCREW	5131032090	4058546131890
1012	1	PART NOT DEATAILED	1000063920	
1013	1	NUT	5131000000	
1014	1	ARMATURE	5131041206	4058546064709
1015	1	DUST CAP	5131041207	4058546064716
1016	1	RUBBER BUMPER	5131031109	4058546127787
1017	1	SCREW	5131031110	4058546127794
1018	1	TRIGGER	5131041208	4058546064723
1019	1	WORM GEAR WHEEL	5131041209	4058546064730
1020	1	SPRING	5131041210	4058546064747
1021	1	CUTTING GUARD	5131031116	4058546127848
1022	1	RETAINING RING	5131031117	4058546127855
1023	1	FLANGE WASHER	5131031118	4058546127862
1024	1	FLANGE WASHER	5131041211	4058546064754
1025	1	SCREW	5131041212	4058546064761
1026	1	FLANGE NUT	5131031946	4058546056780
1027	1	RETAINING RING	5131031128	4058546127954
1028	1	SWITCH LEVER	5131041213	4058546064778
1029	1	BASE PLATE	5131041214	4058546064785
1030	1	FASTENING BOLT	5131031126	4058546127930
1031	1	NUT	5131030416	4058546186029
1032	1	SCREW	5131030417	4058546124663
1034	1	REBATE DEPTH GAUGE	5131041215	4058546064792
1035	1	CONNECTOR	5131041216	4058546064808
1036	1	KNOB	5131041217	4058546064815
1040	1	LABEL	5131037421	4002395282005
1041	1	LABEL	5131041218	4058546064822
1042	1	LABEL	5131041219	4058546064839
1043	1	LABEL	5131041220	4058546064846
1044	1	LABEL	5131041221	4058546064853
1033	1	CSB184A1 184MM CIRCULAR SAW BLADE XXX	5132003615	4892210157645